

MAB-T600-B1

Barebone System with RX680H Chipset

Quick Reference Guide

1st Ed –20 March 2024

Copyright Notice

Copyright © 2024 Avalue Technology Inc., ALL RIGHTS RESERVED.

Document Amendment History

Revision	Date	By	Comment
1 st	March 2024	Avalue	Initial Release

Declaration of Conformity



This device complies with part 15 fcc rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference.

(2) This device must accept any interference received including interference that may cause undesired operation.

This equipment has been tested and found to comply with the limits for a class "a" digital device, pursuant to part 15 of the fcc rules.

These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communications.

Operation of this equipment in a residential area is likely to cause harmful interference in which case the user will be required to correct the interference at his own expense.

CE statement

The product(s) described in this manual complies with all application European Union (CE) directives if it has a CE marking. For computer systems to remain CE compliant, only CE-compliant parts may be used. Maintaining CE compliance also requires proper cable and cabling techniques.



MEDICAL - GENERAL MEDICAL EQUIPMENT AS TO ELECTRICAL
SHOCK, FIRE AND MECHANICAL HAZARDS ONLY IN ACCORDANCE
ANSI/AAMI ES60601-1 (2005) + AMD 1 (2012)
CAN/CSA-C22.2 No. 60601-1 (2014)

Notice

This guide is designed for experienced users to setup the system within the shortest time. For detailed information, please always refer to the electronic user's manual.

Copyright Notice

© 2024 by Avalue Technology Inc. All rights are reserved. No parts of this manual may be copied, modified, or reproduced in any form or by any means for commercial use without the prior written permission of Avalue Technology Inc. All information and specification provided in this manual are for reference only and remain subject to change without prior notice.

Acknowledgements

Intel and Pentium are trademarks of Intel Corporation.

Microsoft Windows is registered trademark of Microsoft Corp.

All other product names or trademarks are properties of their respective owners.

Disclaimer

This manual is intended to be used as a practical and informative guide only and is subject to change without notice. It does not represent a commitment on the part of Avalue. This product might include unintentional technical or typographical errors. Changes are periodically made to the information herein to correct such errors, and these changes are incorporated into new editions of the publication.

A Message to the Customer

Avalue Customer Services

Each and every Avalue's product is built to the most exacting specifications to ensure reliable performance in the harsh and demanding conditions typical of industrial environments. Whether your new Avalue device is destined for the laboratory or the factory floor, you can be assured that your product will provide the reliability and ease of operation for which the name Avalue has come to be known.

Your satisfaction is our primary concern. Here is a guide to Avalue's customer services. To ensure you get the full benefit of our services, please follow the instructions below carefully.

Technical Support and Assistance

1. Visit the Avalue website at <https://www.avalue.com/> where you can find the latest information about the product.
2. Contact your distributor or our technical support team or sales representative for technical support if you need additional assistance. Please have following information ready before you call:
 - Product name and serial number
 - Description of your peripheral attachments
 - Description of your software (operating system, version, application software, etc.)
 - A complete description of the problem
 - The exact wording of any error messages

To receive the latest version of the user's manual; please visit our Web site at:

www.avalue.com

Product Warranty (Returns & Warranties policy)

1. Purpose

Avalue establishes the following maintenance specifications and operation procedures for providing the best quality of service and shortened repair time to our customers.

2. Warranty

2.1 Warranty Period

Avalue endeavors to offer customers the most comprehensive post-sales services and protection; besides offering a 2-year warranty for standard Avalue products, an extended warranty service can also be provided based on additional request from the customer. Within the warranty period, customers are entitled to receive comprehensive and prompt repair and warranty.

Standard products manufactured by Avalue are offered a 2-year warranty, from the date of delivery from Avalue. For ODM/OEM products manufactured by Avalue or PCBA with conformal coating, will follow up the define warranty of the agreement, otherwise will be offered 1-year warranty for ODM/OEM products but non-warranty for PCBA with conformal coating. For outsourcing parts kit by Avalue (ex: Motherboard, LCD touch panel, CPU, RAM, HDD) are offered a 6-month warranty, and Mobile/Tablet PC battery are offered a warranty of the half year, from the date of delivery by Avalue. Products before the mass production stage, i.e. engineering samples are not applied in this warranty or service policy. For extended warranty and cross-territory services, product defects resulting from design, production process or material are covered by the pre-set warranty period after the date of delivery from Avalue. For non-Avalue products, the product warranty and repair time shall be based on the service standards provided by the original manufacturer; in principle Avalue will provide these products a warranty service for no more than one year.

2.2 Maintenance services within the warranty period

In the case of Avalue product DOA (Defect-on-Arrival) when the customer finds any defect within 1 month after the delivery, Avalue will replace it with a new product in a soonest way. Except for custom products, once the customer is approved of a Cross-Shipment Agreement, which allows for delivery a new product to the customer before receiving the defective one, Avalue will immediately proceed with new product replacement for the said DOA case. On validation of the confirmed defect, Avalue is entitled to reserve the right whether to provide a new product for replacement. For the returned defective new product, it is necessary to verify that there shall be no bruise, alteration, scratch or marking to the appearance, and that none of the delivered accessories missing; otherwise, the customer will be requested to pay a processing fee. On the other hand, if the new product defect is resulting from incorrect configuration or erroneous use by the user instead of any problem of the hardware itself, the customer will also be requested to pay for relevant handling fees.

As for other conditions, Avalue will handle defects by way of repair. The customer will be requested to send the defective product to an Avalue authorized service center, and Avalue will return the repaired product back to the customer as soon as possible.

2.3 Ruling of an out-of-warranty defect

The following situations are not included in the warranty:

- The warranty period has expired.
- Product has been altered or its label of the serial number has been torn off.
- Product functionality issues resulting from improper use by the user, unauthorized dismantle or alteration, unfit operation environment, improper maintenance, accident or other causes. Avalue reserves the right for the ruling of the aforementioned situations.
- Product damage resulting from lightning, flood, earthquake or other calamities.
- The warranty rules of non-Avalue products and accessories shall be in accordance with standards set up by the original manufacturer. These products and accessories include RAM, HDD, FDD, CD-ROM, CPU, FAN, etc.
- Product upgrade request or test request submitted by the customer after expiration of the warranty.
- PCBA with conformal coating.
- Avalue semi-product and outsourced products without Avalue serial number.
- Products before the mass production stage, i.e. engineering samples.

3. Procedure for sending for repair

3.1 Attain a RMA number

A customer's rejected product returned for repair shall have a RMA (Return Merchandise Authorization) number. Without a RMA number, Avalue will not provide any repair service for the rejected product, and the product will be returned to the customer at customer's cost. Avalue will not issue any notice for the return of the product.

Each returned product for repair shall have a RMA number, which is simply the authorization of the return for repair; it is not a guarantee that the returned goods can be repaired or replaced. For applying for a RMA number, the customer may enter the eRMA webpage of Avalue <https://www.avalue.com/en/member> and log-in with an account number and a password authorized by Avalue. The system will then automatically issue a RMA number.

When applying for the RMA number, it is essential to fill in basic information of the customer and the product, together with detailed description of the problem encountered. If possible, avoid using ambiguous words such as "does not work" or "problematic". Without a substantial description of the problem, it is hard to start the repair and will cause prolonged repair time. Lacking detailed statement of fault steps also makes the problem hard to be identified, sometimes resulting in second-time repairs.

In case the customer can't define the cause of problem, please contact Avalue application engineers. Sometimes when the problem can be resolved even before the customer sends back the product.

3.2 Maintenance Charge

Avalue will charge a moderate repair fee for the following conditions:

- The warranty period has expired.
- Product has been altered or its label of the serial number has been torn off.
- Product functionality issues resulting from improper use by the user, unauthorized dismantle or alteration, unfit operation environment, improper maintenance, accident or other causes. Avalue reserves the right for the ruling of the aforementioned situations.
- Product damage resulting from lightning, flood, earthquake or other calamities.
- The warranty rules for non-Avalue products and accessories shall be in accordance with standards set up by the original supplier. These products and accessories include RAM, HDD, FDD, CD-ROM, CPU, FAN, etc.
- Product upgrade request or test request submitted by the customer after expiry of the warranty.
- PCBA with conformal coating.
- Avalue semi-product and outsourced products without Avalue serial number
- Products before the mass production stage, i.e. engineering samples.
- In case the products received are examined as NPF (No Problem Found) within the warranty period, the customer shall be responsible for the freight of both trips.
- Please contact your local distributor to examine in advance to prevent unnecessary freight cost.

For system failure of out-of-warranty products, Avalue will provide a quotation prior to repair service. When the customer applies for the cost, please refer to the Quotation number. In case the customer does not return the DOA product that has already been replaced by a new one, or the customer does not sign back the quotation of the out-of-warranty maintenance, Avalue reserves the right of whether or not to provide the repair service. In case the customer does not reply in 3 months, Avalue shall directly scrap or return the product back to customer at customer's cost without further notice to the customer.

3.3 Maintenance service of phased-out products

For servicing phased-out products, Avalue provides an extended period, starting the date of phase-out, as a guaranteed maintenance period of such products, for continuance of the maintenance service to meet customer's requirements. In case of unexpected factors causing Avalue to be unable to repair/replace a warranted but phased-out product, Avalue will, depending on the availability, upgrade the product (free of charge with continued

warranty period as of the original product), or, give partial refund (based on the length of the remaining warranty period) to solve this kind of problem.

3.4 Maintenance Report

On completion of repair of a defective product, a Maintenance Report indicating the maintenance result and part(s) replaced (if any) will be sent to the customer together with the product. If the customer demands an additional maintenance analysis report, a service fee of various level will be charged depending on the warranty status. In case the analysis result shows that the defect attributes to Avalue's faulty design or process, the analysis fee will be exempted.

4. Service Products

Avalue provides service products to manage with different customer needs. Should you have any need, please consult to Avalue Sales Department.

Defect Analysis Report (DAR)

Avalue provides DAR (Defect Analysis Report) services aiming to elevating customer satisfaction. A DAR includes defect cause identification/verification/suggestion and improvement precautions, with instructions on correct usage for the avoidance of any reoccurrence.

Upgrade Service

Avalue is capable to provide system upgrade service for customization requirements. This upgrade service is applicable for main parts, such as CPU, memory, HDD, SSD, storage devices; also replacements motherboards of systems. Please contact Avalue sales for details to evaluate the possibility of system upgrade service and obtain information of lead time and price.

Safety Instructions












Safety Precautions









Before installing and using this device, please note the following precautions.

1. Read these safety instructions carefully.
2. Keep this User's Manual for future reference.
3. Disconnected this equipment from any AC outlet before cleaning.
4. For plug-in equipment, the power outlet socket must be located near the equipment and must be easily accessible.
5. Keep this equipment away from humidity.
6. Put this equipment on a reliable surface during installation. Dropping it or letting it fall may cause damage.

7. Make sure the voltage of the power source is correct before connecting the equipment to the power outlet.
8. Use a power cord that has been approved for using with the product and that it matches the voltage and current marked on the product's electrical range label. The voltage and current rating of the cord must be greater than the voltage and current rating marked on the product.
9. Position the power cord so that people cannot step on it. Do not place anything over the power cord.
10. All cautions and warnings on the equipment should be noted.
11. If the equipment is not used for a long time, disconnect it from the power source to avoid damage by transient overvoltage.
12. Never open the equipment. For safety reasons, the equipment should be opened only by qualified service personnel. If one of the following situations arises, get the equipment checked by service personnel:
 - The power cord or plug is damaged.
 - Liquid has penetrated into the equipment.
 - The equipment has been exposed to moisture.
 - The equipment does not work well, or you cannot get it work according to the user's manual.
 - The equipment has been dropped and damaged.
 - The equipment has obvious signs of breakage.
13. CAUTION: Danger of explosion if battery is incorrectly replaced. Replace only with the same or equivalent type recommended by the manufacturer.
14. Equipment intended only for use in a RESTRICTED ACCESS AREA.

Explanation of Graphical Symbols

	Warning	A WARNING statement provides important information about a potentially hazardous situation which, if not avoided, could result in death or serious injury.
	Caution	A CAUTION statement provides important information about a potentially hazardous situation which, if not avoided, may result in minor or moderate injury to the user or patient or in damage to the equipment or other property.
	Note	A NOTE provides additional information intended to avoid inconveniences during operation.
		Direct current.
		Alternating current
		Stand-by, Power on
		FCC Certification
		CE Certification
		Follow the national requirements for disposal of equipment.
		Stacking layer limit
		This side up

		Fragile Packaging
		Beware of water damage, moisture-proof
		Carton recyclable
		Handle with care
		Follow operating instructions of consult instructions for use.
		Storage & Transportation Temperature: -20°C ~ 60°C
		Storage & Transportation Humidity: 10% ~ 95%
		High Temperature

Disposing of your old product

WARNING:

There is danger of explosion if the battery is mishandled or incorrectly replaced. Replace only with the same type of battery. Do not disassemble it or attempt to recharge it outside the system. Do not crush, puncture, dispose of in fire, short the external contacts, or expose to water or other liquids. Dispose of the battery in accordance with local regulations and instructions from your service provider.

CAUTION:

- Lithium Battery Caution: Danger of explosion if battery is incorrectly replaced. Replace only with same or equivalent type. Dispose batteries according to manufacturer's instructions.
- Disposal of a BATTERY into fire or a hot oven, or mechanically crushing or cutting of a BATTERY, that can result in an EXPLOSION
- Leaving a BATTERY in an extremely high temperature surrounding environment that can result in an EXPLOSION or the leakage of flammable liquid or gas.
- A BATTERY subjected to extremely low air pressure that may result in an EXPLOSION or the leakage of flammable liquid or gas.

Mise en garde!

AVERTISSEMENT : Il existe un risque d'explosion si la batterie est mal manipulée ou remplacée de manière incorrecte. Remplacez uniquement par le même type de batterie. Ne le démontez pas et ne tentez pas de le recharger en dehors du système. Ne pas écraser, percer, jeter au feu, court-circuiter les contacts externes ou exposer à l'eau ou à d'autres liquides. Jetez la batterie conformément aux réglementations locales et aux instructions de votre fournisseur de services.

MISE EN GARDE:

- Pile au lithium Attention : Danger d'explosion si la pile n'est pas remplacée correctement. Remplacer uniquement par un type identique ou équivalent. Jetez les piles conformément aux instructions du fabricant.
- L'élimination d'une BATTERIE dans le feu ou dans un four chaud, ou l'écrasement ou le découpage mécanique d'une BATTERIE, pouvant entraîner une EXPLOSION
- Laisser une BATTERIE dans un environnement à température extrêmement élevée pouvant entraîner une EXPLOSION ou une fuite de liquide ou de gaz inflammable.
- UNE BATTERIE soumise à une pression d'air extrêmement basse pouvant entraîner une EXPLOSION ou une fuite de liquide ou de gaz inflammable.

Content

1.	Getting Started	16
1.1	Packing List.....	16
1.2	System Specifications	18
1.3	System Overview	21
1.3.1	I/O View	21
1.4	System Dimensions	22
1.5	Operating Principle.....	23
2	Hardware Configuration	24
2.1	Powering On the System.....	25
2.2	Connecting to Power Supply	25
2.3	RX680R Overviews.....	26
2.4	RX680R Jumpers & Connectors list.....	27
2.5	RX680R Jumpers & Connectors settings.....	29
2.5.1	Clear CMOS (CMOS1)	29
2.5.2	AT/ATX Mode Select (AT1)	29
2.5.3	COM POWER SETTING (J56,J45~J48,J25).....	30
2.5.4	LVDS Panel Power Select (PANEL_SEL1).....	30
2.5.5	LVDS Backlight Voltage Selection (BKLVOL1)	31
2.5.6	CPU and System fan connectors (CPU_FAN1, SYS_FAN1, SYS_FAN2)	31
2.5.7	System Panel (FIO_PANEL1)	32
2.5.8	ATX power connectors (ATX24P_1 & ATX12V)	32
2.5.9	Serial Port connectors (COM1~6).....	33
2.5.10	Serial ATA connectors (SATA1~4)	33
2.5.11	USB connectors (USB2_HR1, USB2_HR2, USB2_HR3, USB2_HR4).....	34
2.5.12	USB3.2 connector (USB3_HR1).....	34
2.5.13	Front Audio connector (FIO_AUD1)	35
2.5.14	Amplifier connector (SPK1)	35
2.5.15	LVDS connector (LVDS1)	36
2.5.16	LVDS Backlight connector (BKLT1)	37
2.5.17	LAN LED status connector (LAN_LED1).....	37
2.5.18	Chassis intrusion connector (INTRUD1)	38
2.5.19	8-bit GPIO header (GPIO_HDR1)	38
2.5.20	SMBUS/I2C/KMBS connectors (J_SMB1, J_I2C1, J57)	39
3.	BIOS Setup	40
3.1	Introduction	41

3.2	Starting Setup	41
3.3	Using Setup	42
3.4	Getting Help	43
3.5	In Case of Problems	43
3.6	BIOS setup	44
3.6.1	Main Menu	44
3.6.1.1	System Date	44
3.6.1.2	System Time	44
3.6.2	Advanced Menu	45
3.6.2.1	CPU Configuration	45
3.6.2.1.1	Power & Performance	46
3.6.2.2	PCH-FW configuration	46
3.6.2.2.1	TPM Config	47
3.6.2.3	Trusted Computing	47
3.6.2.4	ACPI Settings	48
3.6.2.5	NCT6126D Super IO configuration	49
3.6.2.5.1	Serial Port 1 Configuration	49
3.6.2.5.2	Serial Port 2 Configuration	50
3.6.2.5.3	Serial Port 3 Configuration	50
3.6.2.5.4	Serial Port 4 Configuration	51
3.6.2.5.5	Serial Port 5 Configuration	51
3.6.2.5.6	Serial Port 6 Configuration	52
3.6.2.5.7	Parallel Port Configuration	52
3.6.2.6	Hardware monitor	53
3.6.2.6.1	Smart FAN	53
3.6.2.6.1.1	Front FAN Setting	54
3.6.2.6.1.2	CPU FAN Setting	55
3.6.2.6.1.3	Rear FAN Setting	56
3.6.2.7	S5 RTC wake settings	57
3.6.2.8	AMI Graphic Output Protocol Policy	58
3.6.2.9	USB Configuration	59
3.6.2.10	Network Stack Configuration	60
3.6.2.11	NVMe Configuration	61
3.6.3	Chipset	61
3.6.3.1	System Agent (SA) Configuration	62
3.6.3.1.1	Memory Configuration	62
3.6.3.1.2	Graphics Configuration	63
3.6.3.1.3	VMD setup menu	64
3.6.3.2	PCH-IO Configuration	64
3.6.3.2.1	PCI Express Configuration	65

3.6.3.2.1.1 PCI Express M.2 E	66
3.6.3.2.1.2 PCI Express M.2 M.....	67
3.6.3.2.1.3 PCI Express X4 Open End	68
3.6.3.2.1.4 PCI Express X4 SLOT3.....	69
3.6.3.2.1.5 PCI Express X4 SLOT4	70
3.6.3.2.1.6 M.2 E CNVi Configuration	71
3.6.3.2.2 SATA Configuration	72
3.6.3.2.3 USB Configuration	72
3.6.3.2.4 HD Audio Configuration	73
3.6.4 Security	74
3.6.4.1 HDD Security	75
3.6.4.2 Security Boot	76
3.6.4.2.1 Key Management.....	77
3.6.5 Boot.....	78
3.6.6 Save & Exit	80
3.6.6.1 AMI FW update interface	81
3.6.7 MEBx	82
4. Maintenance & Troubleshooting.....	83
5. Product Application	89

1. Getting Started

1.1 Packing List

Before installation, please ensure all the items listed in the following table are included in the package.

Item	Description	Q'ty
1	MAB-T600-B1 Barebone system	1
2	Power cord	1



If any of the above items is damaged or missing, contact your retailer.

Unpacking

Note:

If any of the components listed in the checklist below are missing, do not proceed with the installation. Contact the Avalue reseller or vendor the product was purchased from or contact an Avalue sales representative directly by sending an email to sales@avalue.com.

To unpack the flat bezel box PC, follow the steps below.

Step 1: Carefully cut the tape sealing the box. Only cut deep enough to break the tape.

Step 2: Open the outside box.

Step 3: Carefully cut the tape sealing the box. Only cut deep enough to break the tape.

Step 4: Open the inside box.

Step 5: Lift the box PC out of the boxes.

Step 6: Remove the peripheral parts box from the main box.

1.2 System Specifications

System	
Processor	12/13th Generation Intel® Core™ i3/i5/i7 Processors. Max TDP 65W
Platform Controller Hub	Intel® R680E PCH
System Memory	4 x DIMM up to 128GB Max Dual Channel DDR5 4400 MHz with ECC Support
I/O Chipset	Nuvoton®
BIOS Information	AMI uEFI BIOS, 256Mbit SPI Flash ROM
Watchdog Timer	H/W Reset, 5~255 seconds/5~255 minutes
H/W Status Monitor	CPU temperature monitoring, Voltages monitoring, CPU fan speed control
RAID	Supports RAID 0, 1
TPM	Support onboard TPM 2.0
iAMT	Intel® Active Management Technology 16
SBC	RX680R
Expansion	
M.2 (Signal)	1 x M.2 M-Key 2242/2280/22110 NVMe (Gen 4 PCIe x4 + SATA III) 1 x M.2 M-Key 2242/2280/22110 NVMe (Gen 3 PCIe x4 + SATA III) 1 x M.2 E-Key 2230 with CNVi Support (PCIe x 1 + USB 2.0)
PCIe (Gen X)	1 x Gen 5 PCIe x16 2 x Gen 4 PCIe x4 (x16 Physical Yellow) 1 x Gen 3 PCIe x4 Open Ended
Storage	
M.2 (Signal)	1 x M.2 M-Key 2242/2280/22110 NVMe (Gen 4 PCIe x4 + SATA III) 1 x M.2 M-Key 2242/2280/22110 NVMe (Gen 3 PCIe x4 + SATA III) 1 x M.2 E-Key 2230 with CNVi Support (PCIe x 1 + USB 2.0)
2.5" Drive Bay (Height)	2 x 2.5" HDD/SSD Drive (2 x 3.5" HDD/SSD Drive as option)
Front I/O	
USB Port	2 x USB 2.0 (Front I/O)
Power Button	1 x Power Button (with LED indicator)
Rear I/O	
USB Port	6 x USB 3.2 Gen 2x1 Ports 1 x USB 3.2 Gen 2x2 Type-C
DP	4 x DP++
Audio	Line-out, Mic-in
LAN Port	2 x RJ-45
Onboard I/O	

SATA Signal	4 x SATA III Headers
GPIO	1 x 8-bit GPIO Header
USB Port	1 x USB 3.2 Gen 2x1 Header (2 Ports) 4 x USB 2.0 Headers (8 Ports)
CPU/System FAN	JYC1L115ATP LGA1700 65W
Display	
Graphic Chipset	Intel® Integrated UHD Graphic with Xe Architecture (CPU Dependent)
Resolution	DP 1.4a (Max Resolution: 4096x2304 @60Hz)
Audio	
Audio Codec	Realtek HD Audio Codec
Ethernet	
LAN Chipset	Intel® I225-LM 2.5 Gigabit Ethernet Controller
Data Rate Per Port	2.5GbE (I225-LM) 2.5GbE (I225-LM)
Power Requirement	
Power Mode	AT/ATX Mode (Default: ATX mode)
Power Supply Unit	FSP500M-80PA PSU 100-240V (power 500W)—Medical Grade
Mechanical & Environment	
Operating Temp.	0°C ~ 40°C (32°F ~ 104°F) with 0.5m/s air flow
Storage Temp.	-30°C ~ 70°C (-22 ~ 158°F)
Operating Humidity	40°C @ 95% Relative Humidity, Non-condensing
Dimension (W*L*H)	330*344*160mm (TBD)
Weight	7 Kg
Vibration Test	<p>Random Vibration Operation:</p> <ol style="list-style-type: none"> 1. Test PSD : 0.00050513G²/Hz , 0.5 Grms 2. System condition : operation mode 3. Test frequency : 5~500 Hz 4. Test axis : X,Y and Z axis 5. Test time : 30 minutes per each axis 6. IEC60068-2-64 Test Fh <p>6 Storage : SSD</p> <p>Sine Vibration test (Non-operation)</p> <ol style="list-style-type: none"> 1 Test Acceleration : 2G 2 Test frequency : 5~500 Hz 3 Sweep : 1 Oct/ per one minute. (logarithmic) 4 Test Axis : X,Y and Z axis 5 Test time :30 min. each axis


	6 System condition : Non-Operating mode 7. Reference IEC 60068-2-6 Testing procedures Package Vibration Test: 1 Test PSD : 0.026G ² /Hz , 2.16 Grms 2 Test frequency : 5~500 Hz 3 Test axis : X,Y and Z axis 4 Test time : 30 minutes per each axis 5 IEC 60068-2-64 Test Fh
Shock Test	1. Wave form : Half Sine wave 2. Acceleration Rate : 10g 3. Duration Time : 11ms 4. No. of Shock : Z axis 300 times 5. Test Axis: Z axis 6. Operation mode 7. Reference IEC 60068-2-27 Testing procedures Test Eb : Bump Test
Package Vibration Test	1. Test PSD : 0.026G ² /Hz , 2.16 Grms 2. Test frequency : 5~500 Hz 3. Test axis : X,Y and Z axis 4. Test time : 30 minutes per each axis 5. IEC 60068-2-64 Test Fh
Drop Test	Package Drop Reference ISTA 2A, Method : IEC-60068-2-32 Test: Ed Drop Test 1 One corner , three edges, six faces 2 ISTA 2A, IEC-60068-2-32 Test:Ed
IP Rating	IPX1 Grade Protection
Software Support	
OS Information	Windows 10, Windows 11, Linux



Note: Specifications are subject to change without notice.

1.3 System Overview


1.3.1 I/O View



Connectors

Label	Function	Note
Power	Power on button	
USB 2.0	2 x USB2.0 connector	
USB 3.2	6 x USB3.2 connector	
USB Type-C	USB Type-C connector	
LAN	2 x RJ-45 Ethernet	suggest using shielded LAN cables to increase stability.
DP	4 x DP connector	
LINE OUT	Line-out audio jack	
MIC IN	Mic-in audio jack	
Power	Power switch	

1.4 System Dimensions



(Unit: mm)

1.5 Operating Principle

(a) Installation:

- Take the device and accessories from package and put in the suitable place.
- Check the packing list (accessories).
- Connect the power cord to the device.
- Put the plug of power cord into receptacle of power source.
- Press power button "Power Icon" on the device to start the device.

(b) Installation for monitor:

- Plug in the monitor cable (DP).

(c) Installation keyboard and mouse.

- Plug in mouse and keyboard.

(d) Operation for Turn ON the system

- Turn ON the system.
- Press the power ON/OFF icon firmly to turn power ON/OFF.
- The power ON/OFF LED will turn blue to indicate power is on.
- Check with the Icon behavior for power status.

2 Hardware Configuration

For advanced information, please refer to:

- 1- RX680R included in this manual.



Note: If you need more information, please visit our website:

www.avalue.com

2.1 Powering On the System


WARNING:

Make sure a power supply with the correct input voltage is being fed into the system. Incorrect voltages applied to the system may cause damage to the internal electronic components and may also cause injury to the user.


- Power on the system: press the power button for 3 seconds.
- Power off the system: press the power button for 6 seconds.

2.2 Connecting to Power Supply

Connect the power cord to the rear of the Box PC: First, insert the power cord into the power connector at the back of the device. Then, plug the power cord plug into the socket of the power source. Finally, turn on the power switch. The supported power input voltages is 100V-240V.



2.3 RX680R Overviews



2.4 RX680R Jumpers & Connectors list

Jumpers

Label	Function	Note
PANEL_SEL1	LVDS Panel Power Select	2 x 3 header, pitch 2.54mm
BKLVOL1	LVDS Backlight Control	1 x 3 header, pitch 2.00mm
AT1	AT/ATX Mode Select	1 x 3 header, pitch 2.54mm
CMOS1	Clear CMOS	1 x 3 header, pitch 2.00mm
J56,J45~J48,J25	COM1~COM6 Power Setting	2 x 3 header, pitch 2.54mm

Connectors


Label	Function	Note
CPU1	LGA 1700 Socket	
J50~J53	DDR5 UDIMM Slots	Dual channel (2DPC)
PCIE_X16_SLOT1	Gen 5 PCIe	x16 Physical Black (Slot1)
PCIE_X4_SLOT2	Gen 3 PCIe	x4 Open Ended (Slot 2)
PCIE_X16_SLOT4	Gen 4 PCIe	x4 (x16 Physical Yellow) (Slot 4)
PCIE_X16_SLOT3	Gen 4 PCIe	x4 (x16 Physical Yellow) (Slot 3)
M2M1	Gen 4 PCIe x4 + SATA III	M Key
M2M	Gen 3 PCIe x4 + SATA III	M Key
M2E	PCIe x 1 + USB 2.0 support	
DisplayPort	DisplayPort Connectors x4	
USB3.2	USB 3.2 Type A Connectors x2	
USBC	USB 3.2 Type C Connector x1	
USB3.2+LAN	RJ45 Ethernet Connectors x2	2.5 Gigabit Ethernet
AUDIO	Audio Phone Jack	Lin-out, Mic-in
CPU_FAN1	CPU FAN Connector	WAFER 1x4, 2.54mm
SYS_FAN1	Chassis Fan Connector	WAFER 1x4, 2.54mm
SYS_FAN2	Chassis Fan Connector	WAFER 1x4, 2.54mm
FIO_PANEL1	Front Panel Connector	BOX header 2x5P, 2.54mm
ATX24P_1	ATX Power Connector	PWR Conn 2x12P
ATX12V	12V ATX Power Connector	PWR Conn 2x4P
COM1~COM6	Serial Port Connectors	WAFER 2x5P, 2.00mm
SATA1~4	SATA Connectors	Male Connectors (RED)
USB2_HR1~4	Front USB 2.0 Headers	BOX header 2x5P, 2.54mm

MAB-T600-B1


USB3_HR1	Front USB 3.2 Header	BOX header 2x10P, 2.00mm
FIO_AUD1	Front Audio Connector	BOX header 2x5P, 2.54mm
SPK1	Amplifier Connector	WAFER 1x4P, 2.00mm
LVDS1	LVDS signals connector	Con. 2x20P, 1.25mm
INTRUD1	Chassis Intrusion Header	WAFER 1x2P, 2.54mm
LAN_LED1	LAN LED Header	2x5 header, 2.54mm
BKLT1	LVDS Backlight Control header	WAFER 1x5P, 2.00mm
LPT1	Parallel Port Connector	WAFER 2x13P, 2.0mm
GPIO_HDR1	GPIO 8 bits Connector	WAFER 2x6P, 2.00mm
J_I2C1	I2C Connector	WAFER 1x4P, 2.00mm
J_SMB1	SMBUS Connector	WAFER 1x5P, 2.00mm
SPI_HDR1	SPI Header	2x4 header, 2.54mm
J6	eSPI Header	2x5 header, 2.00mm
J57	KBMS Header	WAFER 1x 6P, 2.54mm

2.5 RX680R Jumpers & Connectors settings


2.5.1 Clear CMOS (CMOS1)



Normal*




Clear CMOS




* Default


2.5.2 AT/ATX Mode Select (AT1)



ATX mode *





AT mode





* Default

2.5.3 COM POWER SETTING (J56,J45~J48,J25)




* Default

2.5.4 LVDS Panel Power Select (PANEL_SEL1)




* Default


2.5.5 LVDS Backlight Voltage Selection (BKLVL1)



+3V *





+5V





* Default

2.5.6 CPU and System fan connectors (CPU_FAN1, SYS_FAN1, SYS_FAN2)




2.5.7 System Panel (FIO_PANEL1)




- | | |
|------------|------------|
| 1.HDD LED+ | 2.PWR LED+ |
| 3.HDD LED- | 4.PWR LED- |
| 5.GND | 6.PWR_BTN |
| 7.RST | 8.GND |
| 9.NA | 10.KEY |


2.5.8 ATX power connectors (ATX24P_1 & ATX12V)





ATX12V



ATX24P_1




2.5.9 Serial Port connectors (COM1~6)



- | | |
|--------|--------|
| 8.NCTS | 7.NRTS |
| 6.NDSR | 5.GND |
| 4.NDTR | 3.NTX |
| 2.NRX | 1.NDCD |



2.5.10 Serial ATA connectors (SATA1~4)



1. GND
2. TX+
3. TX-
4. GND
5. RX-
6. RX+
7. GND



MAB-T600-B1

2.5.11 USB connectors (USB2_HR1, USB2_HR2, USB2_HR3, USB2_HR4)




10.KEY	9.NC
8.GND	7.GND
6.USB2 D+	5.USB2 D+
4.USB2 D-	3.USB2 D-
2.+5V USB	1.+5V USB

2.5.12 USB3.2 connector (USB3_HR1)





10.NC	19.+5V USB
9.USB2 D+	18.USB3 RX-
8.USB2 D-	17.USB3 RX+
7.GND	16.GND
6.USB3_TX+	15.USB3 TX-
5.USB3_TX-	14.USB3 TX+
4.GND	13.GND
3.USB3_RX+	12.USB2 D-
2.USB3_RX-	11.USB2 D+
1.+5V USB	

2.5.13 Front Audio connector (FIO_AUD1)




- | | |
|---------------|-------------|
| 1.MIC2_L | 2.GND |
| 3.MIC2_R | 4.FP_HDADET |
| 5.LINE2_R | 6.MIC2_JD |
| 7.FR-IO-SENSE | 8.KEY |
| 9.LINE2_L | 10.LINE2_JD |

2.5.14 Amplifier connector (SPK1)




- | |
|---------|
| 1.ROUT- |
| 2.ROUT+ |
| 3.LOUT- |
| 4.LOUT+ |

2.5.15 LVDS connector (LVDS1)





39.BKLT_+12V	40.BKLT_+12V
37.GND	38.GND
35.LS1_CLK_D-	36.LS0_CLK_D-
33.LS1_CLK_D+	34.LS0_CLK_D+
31.GND	32.GND
29.LS1_L3_D-	30.LS1_L2_D-
27.LS1_L3_D+	28.LS1_L2_D+
25.GND	26.GND
23.LS1_L1_D-	24.LS1_L0_D-
21.LS1_L1_D+	22.LS1_L0_D+
19.GND	20.GND
17.LS0_L3_D-	18.LS0_L2_D-
15.LS0_L3_D+	16.LS0_L2_D+
13.GND	14.GND
11.LS0_L1_D-	12.LS0_L0_D-
9.LS0_L1_D+	10.LS0_L0_D+
7.CABLE_ID1	8.GND
5.LS_SCL	6.LS_SDA
3.+3V	4.+5V(PANEL_PWR)
1.+3V	2.+5V(PANEL_PWR)

2.5.16 LVDS Backlight connector (BKLT1)





- 1.+12V_BL
- 2.GND
- 3.BKLT_EN
- 4.BKLT_PWM
- 5.+5V_BL

2.5.17 LAN LED status connector (LAN_LED1)





- | | |
|------------------|------------------|
| 1. 1G_LAN1_LED | 2. 1G_LAN2_LED |
| 3. GND | 4. GND |
| 5. 2.5G_LAN1_LED | 6. 2.5G_LAN2_LED |
| 7. GND | 8. GND |
| 9. LAN1_ACT | 10. LAN2_ACT |

2.5.18 Chassis intrusion connector (INTRUD1)





- 1.PCH_INTRUDER#
- 2.GND

2.5.19 8-bit GPIO header (GPIO_HDR1)



- | | |
|-------------|--------------|
| 1. AP_GPIO1 | 2. AP_GPIO5 |
| 3. AP_GPIO2 | 4. AP_GPIO6 |
| 5. AP_GPIO3 | 6. AP_GPIO7 |
| 7. AP_GPIO4 | 8. AP_GPIO8 |
| 9. SMB_CLK | 10. SMB_DATA |
| 11.GND | 12. +3V_DUAL |

2.5.20 SMBUS/I2C/KMBS connectors (J_SMB1, J_I2C1, J57)



1. +3V_DUAL
2. I2C1_SCL
3. I2C1_SDA
4. GND



1. SMB_CLK
2. SMB_DATA
3. SMB_ALERT
4. GND
5. +3.3V



1. KCLK
2. KDAT
3. MDAT
4. GND
5. +5V_DUAL
6. MCLK

3.BIOS Setup

3.1 Introduction

The BIOS setup program allows users to modify the basic system configuration. In this following chapter will describe how to access the BIOS setup program and the configuration options that may be changed.

3.2 Starting Setup

The AMI BIOS™ is immediately activated when you first power on the computer. The BIOS reads the system information contained in the NVRAM and begins the process of checking out the system and configuring it. When it finishes, the BIOS will seek an operating system on one of the disks and then launch and turn control over to the operating system.

While the BIOS is in control, the Setup program can be activated in one of two ways:

By pressing or <F2> immediately after switching the system on, or

By pressing the or <F2> key when the following message appears briefly at the left-top of the screen during the POST (Power On Self Test).

Press or <F2> to enter SETUP

If the message disappears before you respond and you still wish to enter Setup, restart the system to try again by turning it OFF then ON or pressing the "RESET" button on the system case. You may also restart by simultaneously pressing <Ctrl>, <Alt>, and <Delete> keys. If you do not press the keys at the correct time and the system does not boot, an error message will be displayed and you will again be asked to.

Press F1 to Continue, DEL to enter SETUP

3.3 Using Setup

In general, you use the arrow keys to highlight items, press <Enter> to select, use the PageUp and PageDown keys to change entries, press <F1> for help and press <Esc> to quit. The following table provides more detail about how to navigate in the Setup program using the keyboard.

Button	Description
↑	Move to previous item
↓	Move to next item
←	Move to the item in the left hand
→	Move to the item in the right hand
Esc key	Main Menu -- Quit and not save changes into NVRAM Status Page Setup Menu and Option Page Setup Menu -- Exit current page and return to Main Menu
+ key	Increase the numeric value or make changes
- key	Decrease the numeric value or make changes
F1 key	General help, only for Status Page Setup Menu and Option Page Setup Menu
F2 key	Previous Values.
F3 key	Optimized defaults
F4 key	Save & Exit Setup

- **Navigating Through The Menu Bar**

Use the left and right arrow keys to choose the menu you want to be in.



Note: Some of the navigation keys differ from one screen to another.

- **To Display a Sub Menu**

Use the arrow keys to move the cursor to the sub menu you want. Then press <Enter>. A “➤” pointer marks all sub menus.

3.4 Getting Help

Press F1 to pop up a small help window that describes the appropriate keys to use and the possible selections for the highlighted item. To exit the Help Window press <Esc> or the F1 key again.

3.5 In Case of Problems

If, after making and saving system changes with Setup, you discover that your computer no longer is able to boot, the AMI BIOS supports an override to the NVRAM settings which resets your system to its defaults.

The best advice is to only alter settings which you thoroughly understand. To this end, we strongly recommend that you avoid making any changes to the chipset defaults. These defaults have been carefully chosen by both BIOS Vendor and your systems manufacturer to provide the absolute maximum performance and reliability. Even a seemingly small change to the chipset setup has the potential for causing you to use the override.

3.6 BIOS setup

When you enter the BIOS, the following screen appears. The BIOS menu screen displays the items that allow you to make changes to the system configuration. To access the menu items, press the up/down/right/left arrow key on the keyboard until the desired item is highlighted, then press [Enter] to open the specific menu.

3.6.1 Main Menu

This section allows you to record some basic hardware configurations in your computer and set the system clock.

Main	Advanced	Chipset	Security	Boot	Save & Exit	MEBx
BIOS Information						Item help
BIOS Vendor			American Megatrends			
Core Version			5.25			
Compliance			UEFI 2.8 ; PI 1.7			
BIOS Version			RX680R (71881) BIOS V0.01			
Build Date			01/27/2022			
Processor Information						
Name			AlderLake DT			
Type			12 th Gen Intel(R) Core(TM) i3-12100TE			
Total Memory			32768 MB			↑↓: Select Item
Memory Data Rate			4400 MHz			Enter: Select
ME FW Version			16.0.0.1435			+/- : Change Opt.
System Date			[Www mm/dd/yyyy]			F1: General Help
System Time			[hh:mm:ss]			F2: Previous Values
						F3: Optimized Defaults
						F4: Save & Reset
						ESC: Exit
Version 2.21.1278. Copyright (C) 2021 AMI						

3.6.1.1 System Date

Use the system date option to set the system date. Manually enter the month, day and year.

3.6.1.2 System Time

Use the system time option to set the system time. Manually enter the hours, minutes and seconds.



Note: The BIOS setup screens shown in this chapter are for reference purposes only, and may not exactly match what you see on your screen.

Visit the Avalue website (www.avalue.com) to download the latest product and BIOS information.

3.6.2 Advanced Menu

This section allows you to configure your CPU and other system devices for basic operation through the following sub-menus.

Main	Advanced	Chipset	Security	Boot	Save & Exit	MEBx
▶ CPU Configuration ▶ PCH-FW Configuration ▶ Trusted Computing ▶ ACPI Settings ▶ NCT6126D Super IO Configuration ▶ Hardware Monitor ▶ S5 RTC Wake Settings ▶ AMI Graphic Output Protocol Policy ▶ USB Configuration ▶ Network Stack Configuration ▶ NVMe Configuration						Item help ↑↓: Select Item Enter: Select +/- : Change Opt F1: General Help F2: Previous Values F3: Optimized Defaults F4: Save & Reset ESC: Exit
Version 2.21.1278. Copyright (C) 2021 AMI						

3.6.2.1 CPU Configuration

Main	Advanced	Chipset	Security	Boot	Save & Exit	MEBx
CPU Configuration ▶ Efficient-core Information ▶ Performance-core Information ID 0x90675 Brand String 12 th Gen Intel® Core™ i3-12100TE VMX Supported SMX/TXT Not Supported TXT Crash Code 0x00000000 TXT SPAD 0x0000000000000000 Boot Guard Status 0x00000000 Boot Guard ACM Policy Status 0x0000000000000000 Boot Guard SACM Information 0x0000000000000000						Item help →←: Select Screen ↑↓: Select Item Enter: Select F1: General Help F2: Previous Values F3: Optimized Defaults F4: Save & Reset ESC: Exit
Intel Trusted Execution Technology [Disabled]						
Version 2.21.1278. Copyright (C) 2021 AMI						

- **Intel Trusted Execution Technology [Disabled]**

Enables utilization of additional hardware capabilities provided by Intel® Trusted Execution Technology. Changes require a full power cycle to take effect

Configuration options: [Disabled] [Enabled]

3.6.2.1.1 Power & Performance

Main	Advanced	Chipset	Security	Boot	Save & Exit	MEBx
Performance-core Information						Item help
Frequency						
3000 MHz						
L1 Data Cache						
48 KB x 6						
L1 Instruction Cache						
32 KB x 6						
L2 Cache						
1280 KB x 6						
L3 Cache						
18 MB						
L4 Cache						
N/A						
						→←: Select Screen
						↑↓: Select Item
						Enter: Select
						+/- : Change Opt
						F1: General Help
						F2: Previous Values
						F3: Optimized Defaults
						F4: Save & Reset
						ESC: Exit
Version 2.21.1278. Copyright (C) 2021 AMI						

3.6.2.2 PCH-FW configuration

Configure Management Engine Technology Parameters

Main	Advanced	Chipset	Security	Boot	Save & Exit	MEBx
ME Firmware Version						Item help
16.0.15.1620						
ME Firmware Mode						
Normal Mode						
ME Firmware SKU						
Corporate SKU						
ME Firmware Status 1						
0x90000255						
ME Firmware Status 2						
0x30858106						
ME Firmware Status 3						
0x00000030						
ME Firmware Status 4						
0x00004000						
ME Firmware Status 5						
0x00000000						
ME Firmware Status 6						
0x00400002						
ME State						
[Enabled]						
AMT BIOS Feature						
[Enabled]						
▶ TPM Config						↑↓: Select Item
						+/- : Change Opt
						F1: General Help
						F2: Previous Values
						F3: Optimized Defaults
						F4: Save & Reset
						ESC: Exit
Version 2.21.1278. Copyright (C) 2021 AMI						

- **ME State [Enabled]**

When Disabled ME will be put into ME Temporarily Disabled Mode
options: [Disabled] [Enabled]

- **AMT BIOS Features [Enabled]**

When disabled AMT BIOS Features are no longer supported and user is no longer able to access MEBx Setup. Note: This option does not disable Manageability Features in FW
options: [Disabled] [Enabled]

3.6.2.2.1 TPM Config

Main	Advanced	Chipset	Security	Boot	Save & Exit	MEBx
PTT Capability / State				1 / 0		Item help
TPM Device Selection				[dTPM]		
						→←: Select Screen ↑↓: Select Item Enter: Select +/- : Change Opt F1: General Help F2: Previous Values F3: Optimized Defaults F4: Save & Reset ESC: Exit
Version 2.21.1278. Copyright (C) 2021 AMI						

- **TPM Device Selection [dTPM]**

Selects TPM device: PTT or dTPM. PTT – Enables PTT in SkuMgr

dTPM 1.2 – Disables PTT in SkuMgr Warning ! PTT/dTPM will be disabled and all dat saved on it will be lost

options: [dTPM] [PTT]

3.6.2.3 Trusted Computing

Main	Advanced	Chipset	Security	Boot	Save & Exit	MEBx
TPM 2.0 Device Found						Item help
Firmware Version:				7.85		
Vender:				IFX		
Security Device Support				[Enable]		
Pending operation				[None]		
						→←: Select Screen
						↑↓: Select Item
						Enter: Select
						+/- : Change Opt
						F1: General Help
						F2: Previous Values
						F3: Optimized Defaults
						F4: Save & Reset
						ESC: Exit
Version 2.21.1278. Copyright (C) 2021 AMI						

- **Security Device support [Disabled]**

Enable or Disable BIOS support security device

Configuration options: [Enable] [Disable]

- **Pending operation [None]**

Schedule an Operation for the Security Device. NOTE: Your Computer will reboot during restart in order to change State of Security Device

Configuration options: [None] [TPM Clear]

3.6.2.4 ACPI Settings

Main	Advanced	Chipset	Security	Boot	Save & Exit	MEBx
						Item help
Enable ACPI Auto Configuration						[Disabled]
Enable Hibernation						[Enabled]
ACPI Sleep State						[S3 (Suspend to RAM)]
						↑↓: Select Item +/- : Change Opt F1: General Help F2: Previous Values F3: Optimized Defaults F4: Save & Reset ESC: Exit
Version 2.21.1278. Copyright (C) 2021 AMI						

- **Enable ACPI Auto Configuration [Disabled]**

Enables or Disables BIOS ACPI Auto Configuration

Configuration options: [Disabled] [Enabled]

- **Enable Hibernation [Enabled]**

Enable or Disable system ability to Hibernation (OS/S4 Sleep State).

This option may not be effective with some operating systems

Configuration options: [Disabled] [Enabled]

- **ACPI Sleep State [S3 (Suspend to RAM)]**

Select the highest ACPI sleep state the system will enter the SUSPEND button is pressed.

Configuration options: [Suspend Disabled] [S3 (suspend to RAM)]

3.6.2.5 NCT6126D Super IO configuration

Main	Advanced	Chipset	Security	Boot	Save & Exit	MEBx
NCT6126D Super IO Configuration						Item help
Super IO Chip						
NCT6126D						
▶ Serial Port 1 Configuration ▶ Serial Port 2 Configuration ▶ Serial Port 3 Configuration ▶ Serial Port 4 Configuration ▶ Serial Port 5 Configuration ▶ Serial Port 6 Configuration ▶ Parallel Port Configuration						→←: Select Screen ↑↓: Select Item Enter: Select +/- : Change Opt F1: General Help F2: Previous Values F3: Optimized Defaults F4: Save & Reset ESC: Exit
WatchDog Count Mode						[Second]
WatchDog TimeOut Value						0
Version 2.21.1278. Copyright (C) 2021 AMI						

- **WatchDog Count Mode [Second]**

Configure watchDog count mode

Configuration options: [Second] [Minute]

- **WatchDog Timeout value [0]**

Configure watchdog Timeout Value

Configuration options: 0~255

3.6.2.5.1 Serial Port 1 Configuration

Main	Advanced	Chipset	Security	Boot	Save & Exit	MEBx
Serial Port 1 Configuration						Item help
Serial Port						
Device Settings						
Change Settings						
[Enabled]						→←: Select Screen ↑ ↓ : Select Item Enter: Select +/- : Change Opt F1: General Help F2: Previous Values F3: Optimized Defaults F4: Save & Reset ESC: Exit
IO=3F8h; IRQ=4;						
[Auto]						
Version 2.21.1278. Copyright (C) 2021 AMI						

- **Serial Port [Enabled]**

Enable or Disable serial Port (COM)

Configuration options: [Disabled] [Enabled]

- **Change Setting [Auto]**

Select an optimal settings for super IO device

Configuration options: [Auto] [IO=3F8h; IRQ4] [IO=3F8h; IRQ3,4,5,6,7,9,10,11,12]

[IO=2F8h; IRQ3,4,5,6,7,9,10,11,12] [IO=3E8h; IRQ3,4,5,6,7,9,10,11,12]

[IO=2E8h; IRQ3,4,5,6,7,9,10,11,12]

3.6.2.5.2 Serial Port 2 Configuration

Main	Advanced	Chipset	Security	Boot	Save & Exit	MEBx
Serial Port 2 Configuration						Item help
Serial Port				[Enabled]		→←: Select Screen
Device Settings				IO=2F8h; IRQ=3;		↑ ↓ : Select Item
Change Settings				[Auto]		Enter: Select
						+/- : Change Opt
						F1: General Help
						F2: Previous Values
						F3: Optimized Defaults
						F4: Save & Reset
						ESC: Exit
Version 2.21.1278. Copyright (C) 2021 AMI						

- **Serial Port [Enabled]**
Enable or Disable serial Port (COM)
Configuration options: [Disabled] [Enabled]
- **Change Setting [Auto]**
Select an optimal settings for super IO device
Configuration options: [Auto] [IO=2F8h; IRQ4] [IO=3F8h; IRQ3,4,5,6,7,9,10,11,12]
[IO=2F8h; IRQ3,4,5,6,7,9,10,11,12] [IO=3E8h; IRQ3,4,5,6,7,9,10,11,12]
[IO=2E8h; IRQ3,4,5,6,7,9,10,11,12]

3.6.2.5.3 Serial Port 3 Configuration

Main	Advanced	Chipset	Security	Boot	Save & Exit	MEBx
Serial Port 3 Configuration						Item help
Serial Port				[Enabled]		→←: Select Screen
Device Settings				IO=3E8h; IRQ=7;		↑ ↓ : Select Item
Change Settings				[Auto]		Enter: Select
						+/- : Change Opt
						F1: General Help
						F2: Previous Values
						F3: Optimized Defaults
						F4: Save & Reset
						ESC: Exit
Version 2.21.1278. Copyright (C) 2021 AMI						

- **Serial Port [Enabled]**
Enable or Disable serial Port (COM)
Configuration options: [Disabled] [Enabled]
- **Change Setting [Auto]**
Select an optimal settings for super IO device
Configuration options: [Auto] [IO=3E8h; IRQ7] [IO=3E8h; IRQ3,4,5,6,7,9,10,11,12]
[IO=2E8h; IRQ3,4,5,6,7,9,10,11,12] [IO=220h; IRQ3,4,5,6,7,9,10,11,12]
[IO=228h; IRQ3,4,5,6,7,9,10,11,12]

3.6.2.5.4 Serial Port 4 Configuration

Main	Advanced	Chipset	Security	Boot	Save & Exit	MEBx
Serial Port 4 Configuration						Item help
Serial Port				[Enabled]		→ ← : Select Screen
Device Settings				IO=2E8h; IRQ=7;		↑ ↓ : Select Item
Change Settings				[Auto]		Enter: Select
						+/- : Change Opt
						F1: General Help
						F2: Previous Values
						F3: Optimized Defaults
						F4: Save & Reset
						ESC: Exit
Version 2.21.1278. Copyright (C) 2021 AMI						

- **Serial Port [Enabled]**
Enable or Disable serial Port (COM)
Configuration options: [Disabled] [Enabled]
- **Change Setting [Auto]**
Select an optimal settings for super IO device
Configuration options: [Auto] [IO=2E8h; IRQ6] [IO=3E8h; IRQ3,4,5,6,7,9,10,11,12]
[IO=2E8h; IRQ3,4,5,6,7,9,10,11,12] [IO=220h; IRQ3,4,5,6,7,9,10,11,12]
[IO=228h; IRQ3,4,5,6,7,9,10,11,12]

3.6.2.5.5 Serial Port 5 Configuration

Main	Advanced	Chipset	Security	Boot	Save & Exit	MEBx
Serial Port 5 Configuration						Item help
Serial Port				[Enabled]		→←: Select Screen
Device Settings				IO=220h; IRQ=7;		↑ ↓: Select Item
Change Settings				[Auto]		Enter: Select
						+/- : Change Opt
						F1: General Help
						F2: Previous Values
						F3: Optimized Defaults
						F4: Save & Reset
						ESC: Exit
Version 2.21.1278. Copyright (C) 2021 AMI						

- **Serial Port [Enabled]**
Enable or Disable serial Port (COM)
Configuration options: [Disabled] [Enabled]
- **Change Setting [Auto]**
Select an optimal settings for super IO device
Configuration options: [Auto][IO=220h; IRQ10][IO=3E8h; IRQ3,4,5,6,7,9,10,11,12]
[IO=2E8h; IRQ3,4,5,6,7,9,10,11,12] [IO=220h; IRQ3,4,5,6,7,9,10,11,12]
[IO=228h; IRQ3,4,5,6,7,9,10,11,12]

3.6.2.5.6 Serial Port 6 Configuration

Main	Advanced	Chipset	Security	Boot	Save & Exit	MEBx
Serial Port 6 Configuration						Item help
Serial Port				[Enabled]		→←: Select Screen
Device Settings				IO=228h; IRQ=7;		↑ ↓: Select Item
Change Settings				[Auto]		Enter: Select
Mode Configuration				[3T/5R RS232]		+/- : Change Opt
						F1: General Help
						F2: Previous Values
						F3: Optimized Defaults
						F4: Save & Reset
						ESC: Exit
Version 2.21.1278. Copyright (C) 2021 AMI						

- **Serial Port [Enabled]**

Enable or Disable serial Port (COM)

Configuration options: [Disabled] [Enabled]

- **Change Setting [Auto]**

Select an optimal settings for super IO device

Configuration options: [Auto][IO=228h; IRQ11][IO=3E8h; IRQ3,4,5,6,7,9,10,11,12]

[IO=2E8h; IRQ3,4,5,6,7,9,10,11,12] [IO=220h; IRQ3,4,5,6,7,9,10,11,12]

[IO=228h; IRQ3,4,5,6,7,9,10,11,12]

3.6.2.5.7 Parallel Port Configuration

Main	Advanced	Chipset	Security	Boot	Save & Exit	MEBx
Parallel Port Configuration						Item help
Serial Port				[Enabled]		→←: Select Screen
Device Settings				IO=278h; IRQ=5;		↑ ↓: Select Item
Change Settings				[Auto]		Enter: Select
Device Mode				[STD Printer Mode]		+/- : Change Opt
						F1: General Help
						F2: Previous Values
						F3: Optimized Defaults
						F4: Save & Reset
						ESC: Exit
Version 2.21.1278. Copyright (C) 2021 AMI						

- **Serial Port [Enabled]**

Enable or Disable serial Port (COM)

Configuration options: [Disabled] [Enabled]

- **Change Setting [Auto]**

Select an optimal settings for super IO device

Configuration options: [Auto][IO=378h; IRQ5][IO=378h; IRQ5,6,7,9,10,11,12]

[IO=378h; IRQ5,6,7,9,10,11,12] [IO=278h; IRQ5,6,7,9,10,11,12]

[IO=3BCh; IRQ5,6,7,9,10,11,12]

- **Device Mode [STD Printer Mode]**

Change the Printer Port mode

Configuration options: [STD Printer Mode SPP Mode]

[EPP-1.9 and SPP Mode] [EPP-1.7 and SPP Mode ECP Mode]

[ECP and EPP 1.9 Mode] [ECP and EPP 1.7 Mode]

3.6.2.6 Hardware monitor

Display Hardware monitor information

Main	Advanced	Chipset	Security	Boot	Save & Exit	MEBx
PC Health Status						Item help
CPU Temperature						: xx °C
CPU VR Temperature						: xx °C
DIMM Temperature						: xx °C
Front Fan Speed						: xxxx RPM
CPU Speed						: xxxx RPM
Rear Fan Speed						: xxxx RPM
VIN0						: x.xxx V
VIN2						: x.xxx V
VCORE						: x.xxx V
VCC3V						: x.xxx V
VSB3V						: x.xxx V
VBAT						: x.xxx V
AVSB						: x.xxx V
▶ Smart Fan Function						
						→←: Select Screen
						↑↓: Select Item
						Enter: Select
						+/- : Change Opt
						F1: General Help
						F2: Previous Values
						F3: Optimized Values
						F4: Save & Reset
						ESC: Exit
Version 2.21.1278. Copyright (C) 2021 AMI						

3.6.2.6.1 Smart FAN

Main	Advanced	Chipset	Security	Boot	Save & Exit	MEBx
▶ Front Fan Setting						Item help
▶ CPU Fan Setting						
▶ Rear Fan Setting						
						F2: Previous Values
						F3: Optimized Defaults
						F4: Save & Reset
						ESC: Exit
Version 2.21.1278. Copyright (C) 2021 AMI						

3.6.2.6.1.1 Front FAN Setting

Main	Advanced	Chipset	Security	Boot	Save & Exit	Item help
Front Fan Setting						
Front Fan Mode				[SMART FAN IV]		
Temperature 1				40		
Temperature 2				50		
Temperature 3				60		
Temperature 4				70		
FD/RPM 1				76		
FD/RPM 2				127		
FD/RPM 3				178		
FD/RPM 4				229		
						→←: Select Screen
						↑ ↓ : Select Item
						Enter: Select
						+/- : Change Opt
						F1: General Help
						F2: Previous Values
						F3: Optimized Defaults
						F4: Save & Reset
Version 2.21.1278. Copyright (C) 2021 AMI						

- **Front Fan Mode [SMART FAN IV]**
Fan control mode select
Configuration options: [Manual mode] [SMART FAN IV]
- **Temperature 1 [40]**
The value of temperature 1
Configuration options: By temperature
- **Temperature 2 [50]**
The value of temperature 2
Configuration options: By temperature
- **Temperature 3 [60]**
The value of temperature 3
Configuration options: By temperature
- **Temperature 4 [70]**
The value of temperature 4
Configuration options: By temperature
- **FD / RPM 1 [76]**
The value of Fan Duty/RPM 1 when temperature is T1
Configuration options: By Fan Duty
- **FD / RPM 2 [127]**
The value of Fan Duty/RPM 2 when temperature is T2
Configuration options: By Fan Duty
- **FD / RPM 3 [178]**
The value of Fan Duty/RPM 3 when temperature is T3
Configuration options: By Fan Duty

- **FD / RPM 4 [229]**

The value of Fan Duty/RPM 4 when temperature is T4

Configuration options: By Fan Duty

3.6.2.6.1.2 CPU FAN Setting

Main	Advanced	Chipset	Security	Boot	Save & Exit	
CPU Fan Setting						Item help
CPU Fan Mode						[SMART FAN IV]
Temperature 1						60
Temperature 2						80
Temperature 3						95
Temperature 4						100
FD/RPM 1						76
FD/RPM 2						127
FD/RPM 3						255
FD/RPM 4						255
						→←: Select Screen
						↑ ↓: Select Item
						Enter: Select
						+/-: Change Opt
						F1: General Help
						F2: Previous Values
						F3: Optimized Defaults
						F4: Save & Reset
Version 2.21.1278. Copyright (C) 2021 AMI						

- **CPU Fan Mode [SMART FAN IV]**

Fan control mode select

Configuration options: [Manual mode] [SMART FAN IV]

- **Temperature 1 [60]**

The value of temperature 1

Configuration options: By temperature

- **Temperature 2 [80]**

The value of temperature 2

Configuration options: By temperature

- **Temperature 3 [95]**

The value of temperature 3

Configuration options: By temperature

- **Temperature 4 [100]**

The value of temperature 4

Configuration options: By temperature

- **FD / RPM 1 [76]**

The value of Fan Duty/RPM 1 when temperature is T1

Configuration options: By Fan Duty

- **FD / RPM 2 [127]**

The value of Fan Duty/RPM 2 when temperature is T2

Configuration options: By Fan Duty

MAB-T600-B1

- **FD / RPM 3 [255]**

The value of Fan Duty/RPM 3 when temperature is T3

Configuration options: By Fan Duty

- **FD / RPM 4 [255]**

The value of Fan Duty/RPM 4 when temperature is T4

Configuration options: By Fan Duty

3.6.2.6.1.3 Rear FAN Setting

Main	Advanced	Chipset	Security	Boot	Save & Exit	Item	help
Rear Fan Setting							
Rear Fan Mode				[SMART FAN IV]			
Temperature 1				40			
Temperature 2				50			
Temperature 3				60			
Temperature 4				70			
FD/RPM 1				76			
FD/RPM 2				127			
FD/RPM 3				178			
FD/RPM 4				229			
						→←: Select Screen	
						↑ ↓ : Select Item	
						Enter: Select	
						+/- : Change Opt	
						F1: General Help	
						F2: Previous Values	
						F3: Optimized Defaults	
						F4: Save & Reset	
Version 2.21.1278. Copyright (C) 2021 AMI							

- **Rear Fan Mode [SMART FAN IV]**

Fan control mode select

Configuration options: [Manual mode] [SMART FAN IV]

- **Temperature 1 [40]**

The value of temperature 1

Configuration options: By temperature

- **Temperature 2 [50]**

The value of temperature 2

Configuration options: By temperature

- **Temperature 3 [60]**

The value of temperature 3

Configuration options: By temperature

- **Temperature 4 [70]**

The value of temperature 4

Configuration options: By temperature

- **FD / RPM 1 [76]**

The value of Fan Duty/RPM 1 when temperature is T1

Configuration options: By Fan Duty

- **FD / RPM 2 [127]**

The value of Fan Duty/RPM 2 when temperature is T2

Configuration options: By Fan Duty

- **FD / RPM 3 [178]**

The value of Fan Duty/RPM 3 when temperature is T3


Configuration options: By Fan Duty

- **FD / RPM 4 [229]**

The value of Fan Duty/RPM 4 when temperature is T4

Configuration options: By Fan Duty

3.6.2.7 S5 RTC wake settings



- **Wake system from S5 [Disabled]**

Enable or disable System wake on alarm event. Select FixedTime, system will wake on the hr::min::sec specified. Select DynamicTime. System will wake on the current time+Increase minute(s).

Configuration options: [Disabled] [Fixed Time] [Dynamic Time]

3.6.2.8 AMI Graphic Output Protocol Policy

Main	Advanced	Chipset	Security	Boot	Save & Exit	Item	help
Intel (R) Graphics Controller							
Intel (R) GOP Driver [17.0.1073]							
Output Select						[EDP1 + DP1[ACTIVE]]	
Output Panel Type						[Disabled]	
Backlight Control						[PWM Normal]	
LCD Panel Type						[1920x1080 24bit Dual Channel]	
						→←: Select Screen	
						↑↓: Select Item	
						Enter: Select	
						+/- : Change Opt	
						F1: General Help	
						F2: Previous Values	
						F3: Optimized Defaults	
						F4: Save & Reset	
						ESC: Exit	
Version 2.20.1271. Copyright (C) 2018 American Megatrends, Inc.							

- **Output Select [EDP1 + DP1[ACTIVE]]**
Output Interface
Configuration options: [eDP] [DP1] [DP2] [DP3] [DP4]
- **Output Panel Type [Disabled]**
Select Output Panel Type
Configuration options: [eDP] [LVDS] [Disabled]
- **Backlight Control [PWM Normal]**
Back Light Control Setting
Configuration options: [PWM Inverted] [PWM Normal]
- **LVDS Panel Type [1920x1080 24bit Dual Channel]**
Select LVDS panel used by Internal Graphics Device by selecting the appropriate setup item
Configuration options: [800x600 18bit Single Channel]
[1024x768 18bit Single Channel] [1024x768 24bit Single Channel]
[1280x768 18bit Single Channel] [1280x800 24bit Single Channel]
[1280x960 18bit Single Channel] [1280x1024 24bit Single Channel]
[1366x768 18bit Single Channel] [1366x768 24bit Single Channel]
[1440x900 24bit Single Channel] [1440x1050 24bit Single Channel]
[1600x900 24bit Single Channel] [1680x1050 24bit Single Channel]
[1600x1200 24bit Single Channel] [1920x1080 24bit Single Channel]
[1920x1200 24bit Single Channel]

3.6.2.9 USB Configuration

Main	Advanced	Chipset	Security	Boot	Save & Exit
USB Configuration					Item help
USB Module Version					28
USB Controllers:					
1 XHCI					
USB Devices:					
1 Keyboard, 1 Mouse, 2 Hubs					
Legacy USB Support					[Enabled]
XHCI Hand-off					[Enabled]
USB Mass Storage Driver Support					[Enabled]
USB hardware delays and time-outs:					
USB transfer time-out					[20 sec]
Device reset time-out					[20 sec]
Device power-up delay					[Auto]
Mass Storage Devices:					
Version 2.20.1271. Copyright (C) 2018 American Megatrends, Inc.					

- **Legacy USB Support [Enabled]**

Enables Legacy USB support. AUTO option disables legacy support if no USB devices are connected. DISABLE option will keep USB devices available only for EFI applications.

Configuration options: [Disabled] [Enabled]

- **XHCI Hand-off [Enabled]**

This is a workaround for OSes without XHCI hand-off support. The XHCI ownership change should be claimed by XHCI driver.

Configuration options: [Disabled] [Enabled]

- **USB Mass Storage Driver Support [Enabled]**

Enable/Disable USB Mass Storage Driver Support.

Configuration options: [Disabled] [Enabled]

- **USB transfer time-out [20 sec]**

The time-out value for Control, Bulk, and Interrupt transfers.

Configuration options: [10 sec] [20 sec] [[30 sec] [40 sec]

- **Device reset time-out [20 sec]**

USB mass storage device Start Unit command time-out.

Configuration options: [10 sec] [20 sec] [[30 sec] [40 sec]

- **Device power-up delay [Auto]**

MAB-T600-B1

Maximum time the device will take before it properly reports itself to the Host Controller. 'Auto' uses default value: for a Root port it is 100 ms, for a Hub port the delay is taken from Hub descriptor.

Configuration options: [Auto] [Manual]

3.6.2.10 Network Stack Configuration

Main	Advanced	Chipset	Security	Boot	Save & Exit	MEBx
						Item help
Network stack				[Enabled]		
Ipv4 PXE Support				[Disabled]		
Ipv6 PXE Support				[Disabled]		
						→←: Select Screen
						↑↓: Select Item
						Enter: Select
						+/- : Change Opt
						F1: General Help
						F2: Previous Values
						F3: Optimized Defaults
						F4: Save & Reset
						ESC: Exit
Version 2.21.1278. Copyright (C) 2021 AMI						

- **Network Stack [Enabled]**

Enabled/Disabled UEFI Network Stack

Configuration options: [Disabled] [Enabled]

- **IPv4 PXE Support [Disabled]**

Enable/Disable Ipv4 PXE Boot Support. If disabled IPV4 PXE boot support will not be available.

Configuration options: [Disabled] [Enabled]

- **IPv6 PXE Support [Disabled]**

Enable/Disable Ipv6 PXE Boot Support. If disabled IPV6 PXE boot support will not be available.

Configuration options: [Disabled] [Enabled]

3.6.2.11 NVMe Configuration

Main	Advanced	Chipset	Security	Boot	Save & Exit	MEBx
NVMe Configuration						Item help
▶ (Device)						→←: Select Screen ↑↓: Select Item Enter: Select +/- : Change Opt F1: General Help F2: Previous Values F3: Optimized Defaults F4: Save & Reset ESC: Exit ESC: Exit
Version 2.21.1278. Copyright (C) 2021 AMI						

3.6.3 Chipset

Main	Advanced	Chipset	Security	Boot	Save & Exit	MEBx
▶ System Agent (SA) Configuration ▶ PCH-IO Configuration						Item help
						↑↓: Select Item Enter: Select +/- : Change Opt F1: General Help F2: Previous Values F3: Optimized Defaults F4: Save & Reset ESC: Exit
Version 2.21.1278. Copyright (C) 2021 AMI						

3.6.3.1 System Agent (SA) Configuration

Main	Advanced	Chipset	Security	Boot	Save & Exit	MEBx
System Agent (SA) Configuration						Item help
VT-d						Supported
▶ Memory Configuration ▶ Graphics Configuration ▶ VMD setup menu						→←: Select Screen ↑↓: Select Item Enter: Select +/- : Change Opt F1: General Help F2: Previous Values F3: Optimized Defaults F4: Save & Reset ESC: Exit
VT-d						[Enabled]
Version 2.22.1285. Copyright (C) 2022 AMI						

- VT-d [Enabled]

VT-d capability

Configuration options: [Disabled] [Enabled]

3.6.3.1.1 Memory Configuration

Main	Advanced	Chipset	Boot	Security	Save & Exit	MEBx
Memory Configuration						Item help
Memory RC Version						0.0.3.128
Memory Frequency						4400 Mhz
(tCL-tRCD-tRP-tRAS)						36-36-36-71
MC 0 CH 0 DIMM 0						Not Populated / Disabled
MC 0 CH 0 DIMM 1						Not Populated / Disabled
MC 1 CH 0 DIMM 0						Not Populated / Disabled
MC 1 CH 0 DIMM 1						Populated & Enabled
Size						32768 MB (DDR5)
Number of Ranks						2
Manufacturer						Samsung
Version 2.20.1271. Copyright (C) 2018 American Megatrends, Inc.						

3.6.3.1.2 Graphics Configuration

Main	Advanced	Chipset	Security	Boot	Save & Exit	
		Primary Display		[Auto]		Item help
		Internal Graphics		[Auto]		
		PSMI SUPPORT		[Disabled]		→←: Select Screen
		DVMT Pre-Allocated		[64M]		↑↓: Select Item
		DVMT Total Gfx Mem		[256M]		Enter: Select
						+/-: Change Opt
						F1: General Help
						F2: Previous Values
						F3: Optimized Defaults
						F4: Save & Reset
						ESC: Exit
Version 2.20.1271. Copyright (C) 2018 American Megatrends, Inc.						

- **Primary Display [Auto]**

Select which of IGFX/PEG/PCIE graphic device should be primary display or select HG for Hybrid Gfx.

Configuration options: [Auto] [IGFX][PEG slot][PCH PCI] [HG]

- **Internal Graphics [Auto]**

Keep IGFX enabled based on the setup options

Configuration options: [Auto] [Disabled][Enabled]

- **PSMI Support [Disabled]**

PSMI eabled/Disabled

Configuration options: [Disabled][Enabled]

- **DVMT Pre-allocated [64M]**

Select DVMT 5.0 Pre-allocated (Fixed) Graphics memory size used by the internal graphics device.

Configuration options: [64M] [32M/F7] [36M] [40M] [44M] [48M] [52M] [56M] [60M]

- **DVMT Total Gfx Mem [256M]**

Select DVMT5.0 Total Graphic Memory size used by the Internal Graphics Device.

Configuration options: [128M] [256M] [MAX]

3.6.3.1.3 VMD setup menu

Main	Advanced	Chipset	Security	Boot	Save & Exit	
VMD Configuration						Item help
Enable VMD controller [Disabled]						→←: Select Screen ↑↓: Select Item Enter: Select +/-: Change Opt F1: General Help F2: Previous Values F3: Optimized Defaults F4: Save & Reset ESC: Exit
Version 2.20.1271. Copyright (C) 2018 American Megatrends, Inc.						

- **Enable VMD controller [Disabled]**

Enable/Disable to VMD controller

Configuration options: [Disabled][Enabled]

3.6.3.2 PCH-IO Configuration

Main	Advanced	Chipset	Security	Boot	Save & Exit	MEBx
PCH-IO Configuration						Item help
▶ PCI Express Configuration						↑↓: Select Item
▶ SATA Configuration						Enter: Select
▶ USB Configuration						+/- : Change Opt
▶ HD Audio Configuration						F1: General Help
LVDS Board I225 LAN1 Controller						F2: Previous Values
LVDS Board I225 LAN2 Controller						F3: Optimized Defaults
Wake On Lan from LAN Device						F4: Save & Reset
DeepSx Power Policies						ESC: Exit
State After G3						
GPIO Group Control						
Chassis Intrusion						
Version 2.21.1278. Copyright (C) 2021 AMI						

- **LVDS Board I225 LAN1 Controller [Enabled]**

Enable or disable onboard I225 LAN 1.

Configuration options: [Enabled] [Disabled]

- **LVDS Board I225 LAN2 Controller [Enabled]**

Enable or disable onboard I225 LAN 2.

Configuration options: [Enabled] [Disabled]

- **Wake On Lan from LAN Device [Enabled]**

Enable or disable WOL from I225 LAN Device.

Configuration options: [Enabled] [Disabled]

- **DeepSx Power Policies [Disabled]**

Configure the DeepSx Mode configuration.

Configuration options: [Disabled] [Enabled in S4-S5] [Enabled in S5]

- **State After G3 [Last State]**

Specify what state to go to when power is re-applied after a power failure (G3 state).

Configuration options: [S0 State] [S5 State] [Last State]

- **GPIO Group Control [Disabled]**

GPIO Header Control Enable/Disable.

Configuration options: [Disabled] [Enabled]

- **Chassis Intrusion [Disabled]**

Configure Chassis Intrusion.

Configuration options: [Disabled] [Enabled] [Reset]

3.6.3.2.1 PCI Express Configuration

Main	Advanced	Chipset	Boot	Security	Save & Exit
PCI Express Configuration					
<ul style="list-style-type: none"> ▶ PCI Express M.2 E ▶ PCI Express M.2 M ▶ PCI Express X4 Open End ▶ PCI Express X4 SLOT3 ▶ PCI Express X4 SLOT4 ▶ M.2 E CNVi Configuration 					Item help
					→←: Select Screen ↑↓: Select Item Enter: Select +/- : Change Opt F1: General Help F2: Previous Values F3: Optimized Defaults F4: Save & Reset ESC: Exit
Version 2.20.1271. Copyright (C) 2018 American Megatrends, Inc.					

3.6.3.2.1.1 PCI Express M.2 E

Main	Advanced	Chipset	Boot	Security	Save & Exit	
						Item help
				PCI Express M.2 E	[Enabled]	
				ASPM	[L1]	→←: Select Screen
				L1 Substates	[L1.1 & L1.2]	↑↓: Select Item
				PCI Speed	[Auto]	Enter: Select
						+/- : Change Opt
						F1: General Help
						F2: Previous Values
						F3: Optimized Defaults
						F4: Save & Reset
						ESC: Exit
Version 2.20.1271. Copyright (C) 2018 American Megatrends, Inc.						

- **PCI Express M.2 E [Enabled]**
Control the PCI Express Root Port.
Configuration options: [Disabled] [Enabled]
- **ASPM [L1]**
Set the ASPM Level:Force L0s - Force all links to L0s State AUTO - BIOS auto
configure DISABLE - Disables ASPM
Configuration options: [Disabled] [L1] [Auto]
- **L1 Substates [L1.1 & L1.2]**
PCI Express L1 Substates settings.
Configuration options: [Disabled] [L1.1] [L1.1 & L1.2]
- **PCIe Speed [Auto]**
Configure PCIe Speed
Configuration options: [Auto][Gen1][Gen2][Gen3]

3.6.3.2.1.2 PCI Express M.2 M

Main	Advanced	Chipset	Boot	Security	Save & Exit
PCI Express M.2 M [Enabled] ASPM [Disabled] L1 Substates [L1.1 & L1.2] PCI Speed [Auto]					Item help →←: Select Screen ↑↓: Select Item Enter: Select +/-: Change Opt F1: General Help F2: Previous Values F3: Optimized Defaults F4: Save & Reset ESC: Exit
Version 2.20.1271. Copyright (C) 2018 American Megatrends, Inc.					

- **PCI Express M.2 M [Enabled]**

Control the PCI Express Root Port.

Configuration options: [Disabled] [Enabled]

- **ASPM [Disabled]**

Set the ASPM Level: Force L0s - Force all links to L0s State AUTO - BIOS auto configure DISABLE - Disables ASPM

Configuration options: [Disabled] [L1] [Auto]

- **L1 Substates [L1.1 & L1.2]**

PCI Express L1 Substates settings.

Configuration options: [Disabled] [L1.1] [L1.1 & L1.2]

- **PCIe Speed [Auto]**

Configure PCIe Speed

Configuration options: [Auto] [Gen1] [Gen2] [Gen3]

3.6.3.2.1.3 PCI Express X4 Open End

Main	Advanced	Chipset	Boot	Security	Save & Exit	
PCI Express X4 Open End ASPM L1 Substates PCI Speed						Item help
						→←: Select Screen
						↑↓: Select Item
						Enter: Select
						+/- : Change Opt
						F1: General Help
						F2: Previous Values
						F3: Optimized Defaults
						F4: Save & Reset
						ESC: Exit
Version 2.20.1271. Copyright (C) 2018 American Megatrends, Inc.						

- **PCI Express X4 Open End [Enabled]**
Control the PCI Express Root Port.
Configuration options: [Disabled] [Enabled]
- **ASPM [L1]**
Set the ASPM Level:Force L0s - Force all links to L0s State AUTO - BIOS auto configure DISABLE - Disables ASPM
Configuration options: [Disabled] [L1] [Auto]
- **L1 Substates [L1.1 & L1.2]**
PCI Express L1 Substates settings.
Configuration options: [Disabled] [L1.1] [L1.1 & L1.2]
- **PCIe Speed [Auto]**
Configure PCIe Speed
Configuration options: [Auto][Gen1][Gen2][Gen3]

3.6.3.2.1.4 PCI Express X4 SLOT3

Main	Advanced	Chipset	Boot	Security	Save & Exit	
						Item help
PCI Express X4 SLOT3						→←: Select Screen
ASPM						↑↓: Select Item
L1 Substates						Enter: Select
PCI Speed						+/- : Change Opt
						F1: General Help
						F2: Previous Values
						F3: Optimized Defaults
						F4: Save & Reset
						ESC: Exit
Version 2.20.1271. Copyright (C) 2018 American Megatrends, Inc.						

- **PCI Express X4 SLOT3 [Enabled]**

Control the PCI Express Root Port.

Configuration options: [Disabled] [Enabled]

- **ASPM [L1]**

Set the ASPM Level: Force L0s - Force all links to L0s State AUTO - BIOS auto configure DISABLE - Disables ASPM

Configuration options: [Disabled] [L1] [Auto]

- **L1 Substates [L1.1 & L1.2]**

PCI Express L1 Substates settings.

Configuration options: [Disabled] [L1.1] [L1.1 & L1.2]

- **PCIe Speed [Auto]**

Configure PCIe Speed

Configuration options: [Auto][Gen1][Gen2][Gen3]

3.6.3.2.1.5 PCI Express X4 SLOT4

Main	Advanced	Chipset	Boot	Security	Save & Exit	
						Item help
PCI Express X4 SLOT4						→←: Select Screen
ASPM						↑↓: Select Item
L1 Substates						Enter: Select
PCI Speed						+/- : Change Opt
						F1: General Help
						F2: Previous Values
						F3: Optimized Defaults
						F4: Save & Reset
						ESC: Exit
Version 2.20.1271. Copyright (C) 2018 American Megatrends, Inc.						

- **PCI Express X4 SLOT4 [Enabled]**

Control the PCI Express Root Port.

Configuration options: [Disabled] [Enabled]

- **ASPM [L1]**

Set the ASPM Level: Force L0s - Force all links to L0s State AUTO - BIOS auto configure DISABLE - Disables ASPM

Configuration options: [Disabled] [L1] [Auto]

- **L1 Substates [L1.1 & L1.2]**

PCI Express L1 Substates settings.

Configuration options: [Disabled] [L1.1] [L1.1 & L1.2]

- **PCIe Speed [Auto]**

Configure PCIe Speed

Configuration options: [Auto][Gen1][Gen2][Gen3]

3.6.3.2.1.6 M.2 E CNVi Configuration

Main	Advanced	Chipset	Boot	Security	Save & Exit	
CNVi CRF Present				Yes		Item help
CNVi Configuration						
CNVi Mode				[Auto Detection]		→←: Select Screen
Wi-Fi Core				[Enabled]		↑↓: Select Item
BT Core				[Enabled]		Enter: Select
						+/-: Change Opt
						F1: General Help
						F2: Previous Values
						F3: Optimized Defaults
						F4: Save & Reset
						ESC: Exit
Version 2.20.1271. Copyright (C) 2018 American Megatrends, Inc.						

- **CNVi Mode [Auto Detection]**

This option configures Connectivity. [Auto Detection] means that if Discrete solution is discovered it will be enabled by default. Otherwise Integrated solution (CNVi) will be enabled. And [Disable Integrated] is disables Integrated Solution.

NOTE: When CNVi is present, the GPIO pins that are used for radio interface cannot b assigned to the other native function.

Configuration options: [Disable Integrated] [Auto Detection]

- **Wi-Fi Core [Enabled]**

This is an option intended to Enable/Disable Wi-Fi Core in CNVi

Configuration options: [Disabled] [Enabled]

- **BT Core [Enabled]**

This is an option intended to Enable/Disable BT Core in CNVi

Configuration options: [Enabled] [Disabled]

3.6.3.2.2 SATA Configuration

Main	Advanced	Chipset	Boot	Security	Save & Exit	
SATA Configuration						Item help
SATA Mode Selection			[AHCI]			
SATA Port 1			Empty			→←: Select Screen
SATA Port 2			Empty			↑↓: Select Item
SATA Port 3			Empty			Enter: Select
SATA Port 4			Empty			+/- : Change Opt
SATA to M2M1			Empty			F1: General Help
SATA to M2M			Empty			F2: Previous Values
						F3: Optimized Defaults
						F4: Save & Reset
						ESC: Exit
Version 2.20.1271. Copyright (C) 2018 American Megatrends, Inc.						

- **SATA Mode Selection [AHCI]**

Determines how SATA controller(s) operate.

Configuration options: [AHCI] [Intel RST Premium With Intel Optane System Acceleration]

3.6.3.2.3 USB Configuration

Main	Advanced	Chipset	Boot	Security	Save & Exit	
USB Configuration						Item help
xHCI Support				[Disabled]		
Rear IO USB3 Gen1 Power				[Enabled]		→←: Select Screen
Rear IO LAN2 USB3 Gen2 Power				[Enabled]		↑↓: Select Item
Rear IO LAN1 USB3 Gen2 Power				[Enabled]		Enter: Select
Front IO USB3 Gen1 Header Power				[Enabled]		+/- : Change Opt
Front IO USB2 Header 4 Power				[Enabled]		F1: General Help
Front IO USB2 Header 3 Power				[Enabled]		F2: Previous Values
Front IO USB2 Header 2 Power				[Enabled]		F3: Optimized Defaults
Front IO USB2 Header 1 Power				[Enabled]		F4: Save & Reset
						ESC: Exit
Version 2.20.1271. Copyright (C) 2018 American Megatrends, Inc.						

- **xHCI Support [Disabled]**

Enable/Disable xHCI (USB OTG Device).

Configuration options: [Disabled] [Enabled]

- **Rear IO USB3 Gen1 Power [Enabled]**

Enable/Disable Upper/Lower USB ports of HDMI Rack.

Configuration options: [Disabled] [Enabled]

- **Rear IO LAN2 USB3 Gen2 Power [Enabled]**

Enable/Disable Upper/Lower USB ports of i211 RJ45 Rack.

Configuration options: [Disabled] [Enabled]

- **Rear IO LAN1 USB3 Gen2 Power [Enabled]**

Enable/Disable Upper/Lower USB ports of i219 RJ45 Rack.

Configuration options: [Disabled] [Enabled]

- **Front IO USB3 Gen1 Header Power [Enabled]**

Enable/Disable USB3 Gen1 ports of USB3 Header.

Configuration options: [Disabled] [Enabled]

- **Front IO USB2 Header 4 Power [Enabled]**

Enable/Disable USB ports of USB2 Header 4.

Configuration options: [Disabled] [Enabled]

3.6.3.2.4 HD Audio Configuration

Main	Advanced	Chipset	Boot	Security	Save & Exit
HD Audio Subsystem Configuration Settings					
HD Audio				[Enabled]	Item help
					→←: Select Screen ↑↓: Select Item Enter: Select +/- : Change Opt F1: General Help F2: Previous Values F3: Optimized Defaults F4: Save & Reset ESC: Exit
Version 2.20.1271. Copyright (C) 2018 American Megatrends, Inc.					

- **HD Audio [Enabled]**

Control Detection of HD-Audio device.

Disabled = HDA will be unconditionally disabled
 Enabled = HDA will be unconditionally enabled

Configuration options: [Enabled] [Disabled]

3.6.4 Security

Main	Advanced	Chipset	Security	Boot	Save & Exit	MEBx
Password Description If Only the Administrator's password is set, then this only limits access to Setup and is only asked for when entering Setup. If ONLY the User's password is set, then this is a power on password and must be entered to boot or enter Setup. In Setup the User will have Administrator rights.. The password length must be in the following range: Minimum length 3 Maximum length 20						Item help
Administrator Password User Password HDD Security Configuration: HDD Security drive Secure Boot HDD Security Configuration: SSD Security drive						→←: Select Screen ↑↓: Select Item Enter: Select +/- : Change Opt F1: General Help F2: Previous Values F3: Optimized Defaults F4: Save & Reset ESC: Exit
Version 2.21.1278. Copyright (C) 2021 AMI						

- **Administrator Password**

Set Administrator Password

- **User Password**

Set User Password

- **HDD Security drive**

Press Enter when selected to go into the associated Sub-Menu.

- **SSD Security drive**

Press Enter when selected to go into the associated Sub-Menu.

3.6.4.1 HDD Security

Main	Advanced	Chipset	Security	Boot	Save & Exit
HDD Password Description :					Item help
Allows Access to Set, Modify and Clear Hard Disk User Password and Master Password.					
User Password is mandatory to Enable HDD Security.					
If Master password is installed (optional), it can also be used to unlock the HDD.					
If the 'Set User Password' option is hidden, do power cycle to enable the option again.					
HDD PASSWORD CONFIGURATION:					
Security Supported : Yes					→←: Select Screen
Security Enabled : No					↑↓: Select Item
Security Locked : No					Enter: Select
Security Frozen : No					+/- : Change Opt
HDD User Pwd Status : NOT INSTALLED					F1: General Help
Set User Password					F2: Previous Values
					F3: Optimized Defaults
					F4: Save & Reset
					ESC: Exit
Version 2.21.1278. Copyright (C) 2021 AMI					

- **Set User Password**

Set HDD User Password. *** Advisable to Power Cycle System after Setting Hard Disk Passwords ***. Discard or Save changes option in setup does not have any impact on HDD when password is set or removed. If the 'Set HDD User Password' option is hidden, do power cycle to enable the option again.

3.6.4.2 Security Boot

Main	Advanced	Chipset	Security	Boot	Save & Exit
HDD Password Description :					Item help
Allows Access to Set, Modify and Clear Hard Disk User Password and Master Password.					
User Password is mandatory to Enable HDD Security.					
If Master password is installed (optional), it can also be used to unlock the HDD.					
If the 'Set User Password' option is hidden, do power cycle to enable the option again.					
HDD PASSWORD CONFIGURATION:					
Security Supported : Yes					→←: Select Screen
Security Enabled : No					↑↓: Select Item
Security Locked : No					Enter: Select
Security Frozen : No					+/- : Change Opt
HDD User Pwd Status : NOT INSTALLED					F1: General Help
Set User Password					F2: Previous Values
					F3: Optimized Defaults
					F4: Save & Reset
					ESC: Exit
Version 2.21.1278. Copyright (C) 2021 AMI					

- **Secure Boot [Disabled]**

Secure Boot feature is Active if Secure Boot is Enabled, Platform Key(PK) is enrolled and the System is in User mode. The mode change requires platform reset

Configuration options: [Enabled] [Disabled]

- **Secure Boot Mode [Custom]**

Secure Boot mode options: Standard or Custom. In Custom mode, Secure Boot Policy variables can be configured by a physically present user without full authentication

Configuration options: [Standard] [Custom]

3.6.4.2.1 Key Management

Main	Advanced	Chipset	Security	Boot	Save & Exit	MEBx
Vender Key				Valid		Item help
Factory Key Provision				[Disabled]		
▶ Restore Factory Keys						
▶ Reset To Setup Mode						
▶ Export Secure Boot variables						
▶ Enroll Efi Image						
Device Guard ready						
▶ Remove 'UEFI CA' from DB						→←: Select Screen
▶ Restore DB defaults						↑↓: Select Item
						Enter: Select
						+/- : Change Opt.
						F1: General Help
						F2: Previous Values
						F3: Optimized Defaults
						F4: Save & Reset
						ESC: Exit
Version 2.21.1278. Copyright (C) 2021 AMI						

- **Factory Key Provision [Disabled]**

Install factory default Secure Boot keys after the platform reset and while the System is in Setup mode

Configuration options: [Enabled] [Disabled]

3.6.5 Boot

Main	Advanced	Chipset	Security	Boot	Save & Exit	MEBx
Boot Configuration						Item help
Setup Prompt Timeout					1	
Bootup NumLock State					[On]	
FIXED BOOT ORDER Priorities						
Boot Option #1					[USB Floppy]	
Boot Option #2					[CD/DVD]	
Boot Option #3					[USB CD/DVD]	→←: Select Screen
Boot Option #4					[Hard Disk]	↑↓: Select Item
Boot Option #5					[USB Key]	Enter: Select
Boot Option #6					[USB Hard Disk]	+/- : Change Opt.
Boot Option #7					[Network]	F1: General Help
Boot Option #8					[UEFI AP]	F2: Previous Values
▶ UEFI USB Floppy Drive BBS Priorities						F3: Optimized Defaults
▶ UEFI CDROM/DVD Drive BBS Priorities						F4: Save & Reset
▶ UEFI USB CDROM/DVD Drive BBS Priorities						ESC: Exit
▶ UEFI Hard Disk Drive BBS Priorities						
▶ UEFI USB Key Drive BBS Priorities						
▶ UEFI USB Hard Disk Drive BBS Priorities						
▶ UEFI NVME Drive BBS Priorities						
▶ UEFI Network Drive BBS Priorities						
▶ UEFI Application Boot Priorities						
Version 2.21.1278. Copyright (C) 2021 AMI						

- **Setup Prompt Timeout [1]**

Number of seconds to wait for setup activation key. 65535(0xFFFF) means indefinite waiting.

- **Bootup NumLock State [On]**

Select the keyboard NumLock state.

Configuration options: [On] [Off]

- **Boot Option #1 [USB Floppy]**

Sets the system boot order.

Configuration options: [USB Floppy] [CD/DVD] [USB CD/DVD] [Hard Disk] [USB Key] [USB Hard Disk] [NVME] [Network] [UEFI AP] [Disabled]

- **Boot Option #2 [CD/DVD]**

Sets the system boot order.

Configuration options: [USB Floppy] [CD/DVD] [USB CD/DVD] [Hard Disk] [USB Key] [USB Hard Disk] [NVME] [Network] [UEFI AP] [Disabled]

- **Boot Option #3 [USB CD/DVD]**

Sets the system boot order.

Configuration options: [USB Floppy] [CD/DVD] [USB CD/DVD] [Hard Disk] [USB Key] [USB Hard Disk] [NVME] [Network] [UEFI AP] [Disabled]

- **Boot Option #4 [Hard Disk]**

Sets the system boot order.

Configuration options: [USB Floppy] [CD/DVD] [USB CD/DVD] [Hard Disk] [USB Key] [USB Hard Disk] [NVME] [Network] [UEFI AP] [Disabled]

- **Boot Option #5 [USB Key]**

Sets the system boot order.

Configuration options: [USB Floppy] [CD/DVD] [USB CD/DVD] [Hard Disk] [USB Key] [USB Hard Disk] [NVME] [Network] [UEFI AP] [Disabled]

- **Boot Option #6 [USB Hard Disk]**

Sets the system boot order.

Configuration options: [USB Floppy] [CD/DVD] [USB CD/DVD] [Hard Disk] [USB Key] [USB Hard Disk] [NVME] [Network] [UEFI AP] [Disabled]

- **Boot Option #7 [Network]**

Sets the system boot order.

Configuration options: [USB Floppy] [CD/DVD] [USB CD/DVD] [Hard Disk] [USB Key] [USB Hard Disk] [NVME] [Network] [UEFI AP] [Disabled]

- **Boot Option #8 [UEFI AP]**

Sets the system boot order.

Configuration options: [USB Floppy] [CD/DVD] [USB CD/DVD] [Hard Disk] [USB Key] [USB Hard Disk] [NVME] [Network] [UEFI AP] [Disabled]

3.6.6 Save & Exit

Main	Advanced	Chipset	Security	Boot	Save & Exit	MEBx
Save Changes and Reset Discard Changes and Reset Restore Defaults AMIFWUpdate						Item help
						→←: Select Screen ↑↓: Select Item Enter: Select +/-: Change Opt F1: General Help F2: Previous Values F3: Optimized Defaults F4: Save & Reset ESC: Exit
Version 2.21.1278. Copyright (C) 2021 AMI						

- **Save Changes and Reset**

Reset the system after saving the changes.

- **Discard Changes and Reset**

Reset system setup without saving any changes.

- **Restore Defaults**


Restore/Load default values for all the setup option.

- **AMIFWUpdate**

Launches AMIFWUpdate.

3.6.6.1 AMI FW update interface

Update ROM file via the AMI Firmware Update interface, Click “AMIFWupdate” on BIOS setup menu’s “Save and Exit” page and following below steps to update the BIOS.



3.6.7 MEBx

Main	Advanced	Chipset	Security	Boot	Save & Exit	MEBx
Intel® ME Password						<div>Item help</div> <div>MEBx Login</div> <div>→←: Select Screen</div> <div>↑↓: Select Item</div> <div>Enter: Select</div> <div>+/- : Change Opt</div> <div>F1: General Help</div> <div>F2: Previous Values</div> <div>F3: Optimized Defaults</div> <div>F4: Save & Reset</div> <div>ESC: Exit</div>
Version 2.21.1278. Copyright (C) 2021 AMI						

- Intel® ME Password
- MEBx Login.

4. Maintenance & Troubleshooting

System Maintenance Introduction

If the components of the product fail they must be replaced.

Please contact the system reseller or vendor to purchase the replacement parts. Please follow the safety precautions outlined in the sections that follow

General Safety Precautions

Please ensure the following safety precautions are adhered to at all times.

1. Follow the electrostatic precautions outlined below whenever the device is opened.
2. Make sure the power is turned off and the power cord is disconnected whenever the product is being installed, moved or modified.
3. To prevent the risk of electric shock, make sure power cord is unplugged from wall socket. To fully disengage the power to the unit, please disconnect the power cord from the AC outlet. Refer servicing to qualified service personnel. The AC outlet shall be readily available and accessible.
4. Do not apply voltage levels that exceed the specified voltage range. Doing so may cause fire and/or an electrical shock. Use a power cord that matches the voltage of the power outlet, which has been approved and complies with the safety standard of your particular country.
5. Electric shocks can occur if the product chassis is opened when it is running. To avoid risk of electric shock, this device must only be connected to a supply mains with protective earth.
6. Do not drop or insert any objects into the ventilation openings of the product.
7. If considerable amounts of dust, water, or fluids enter the device, turn off the power supply immediately, unplug the power cord, and contact your dealer or the nearest service center.
8. This equipment is not suitable for use in locations where children are likely to be present.
9. DO NOT:
 - Drop the device against a hard surface.
 - In a site where the ambient temperature exceeds the rated temperature.

Anti-Static Precautions

WARNING:

Failure to take ESD precautions during the installation of the product may result in permanent damage to the product and severe injury to the user.

Electrostatic discharge (ESD) can cause serious damage to electronic components, including the product. Dry climates are especially susceptible to ESD. It is therefore critical that whenever the product is opened and any of the electrical components are handled, the following anti-static precautions are strictly adhered to.

- Wear an anti-static wristband: Wearing a simple anti-static wristband can help to prevent ESD from damaging any electrical component.
- Self-grounding: Before handling any electrical component, touch any grounded conducting material. During the time the electrical component is handled, frequently touch any conducting materials that are connected to the ground.
- Use an anti-static pad: When configuring or working with an electrical component, place it on an anti-static pad. This reduces the possibility of ESD damage.
- Only handle the edges of the electrical component. When handling the electrical component, hold the electrical component by its edges. Please ensure the following safety precautions are adhered to at all times.

Maintenance and Cleaning

When maintaining or cleaning the product, please follow the guidelines below.

WARNING:

- For safety reasons, turn-off the power and unplug the box PC before cleaning.
- If you dropped any material or liquid such as water onto the box PC when cleaning, unplug the power cable immediately and contact your dealer or the nearest service center. Always make sure your hands are dry when unplugging the power cable.

Maintenance and Cleaning

Prior to cleaning any part or component of the product, please read the details below.

- Never spray or squirt liquids directly onto any other components. To clean the box PC, gently wipe it with a piece of soft dry cloth or a slightly moistened cloth.
- The interior of the device does not require cleaning. Keep fluids away from the device interior.
- Be cautious of all small removable components when vacuuming the device.
- Never drop any objects or liquids through the openings of the device.
- Be cautious of any possible allergic reactions to solvents or chemicals used when cleaning the device.
- Avoid eating, drinking and smoking within vicinity of the device.

Cleaning Tools

Some components in the box PC may only be cleaned using a product specifically designed for the purpose. In such case, the product will be explicitly mentioned in the cleaning tips. Below is a list of items to use when cleaning the box PC.

- Cloth: Although paper towels or tissues can be used, a soft, clean piece of cloth is recommended when cleaning the device.
- Water or rubbing alcohol: A cloth moistened with water or rubbing alcohol can be used to clean the device.
- Using solvents: The use of solvents is not recommended when cleaning the device as they may damage the plastic parts.
- Vacuum cleaner: Using a vacuum specifically designed for computers is one of the best methods of cleaning the device. Dust and dirt can restrict the airflow in the device and cause its circuitry to corrode.
- Cotton swabs: Cotton swabs moistened with rubbing alcohol or water are excellent tools for wiping hard to reach areas.
- Foam swabs: Whenever possible, it is best to use lint free swabs such as foam swabs for cleaning.

Basic Troubleshooting

PEI Beep Codes

# of Beeps	Description
1	Memory not Installed
2	Recovery started
3	Typically for development use. The beep code is generated when DXE IPL PPI or DXE Core is not found.
4	Recovery failed
4	S3 Resume failed
7	Typically for development use. The beep code is generated when platform cannot be reset because reset PPI is not available.

DXE Beep Codes

# of Beeps	Description
1	Invalid password
4	Typically for development use. The beep code is generated when some of the Architectural Protocols are not available.
5	No Console Input or Output Devices are found
5	No Console Input Devices are found
6	Flash update is failed
7	Typically for development use. The beep code is generated when platform cannot be reset because reset protocol is not available.
8	Platform PCI resource requirements cannot be met

5. Product Application

For detailed instructions on the operation of the Watchdog Timer and Digital I/O (DIO) features of this box PC, please refer to the comprehensive guide available in the "AvalueIOAPI" manual. Please reaching out to your respective distributors, Avalue technical support team, or Avalue customer service representatives for further information. Feel free to inquire about this supplementary resource to enhance your understanding of the Watchdog Timer and Digital I/O (DIO) Application for optimal utilization of your box PC.